
USER MANUAL



AEG

CONTENTS

1. SAFETY INFORMATION	2
1. SALETTINI ONIVIATION	5
2. SAFETY INSTRUCTIONS	
3. PRODUCT DESCRIPTION	
4. CONTROL PANEL	8
5. PROGRAM	9
6. OPTIONS	11
7. BEFORE FIRST USE	12
8. DAILY USE	
9. HINTS AND TIPS	15
10. CARE AND CLEANING	. 16
11. TROUBLESHOOTING	18
12. TECHNICAL DATA	20
13. ACCESSORIES	21
14. PRODUCT INFORMATION SHEET IN REFERENCE TO E.U. REGULATION	
1369/2017	22

FOR PERFECT RESULTS

Thank you for choosing this AEG product. We have created it to give you impeccable performance for many years, with innovative technologies that help make life simpler features you might not find on ordinary appliances. Please spend a few minutes reading to get the very best from it. Visit our website for:



Get usage advice, brochures, trouble shooter, service information: www.aeq.com/webselfservice



Register your product for better service:

www.registeraeg.com



Buy Accessories, Consumables and Original spare parts for your appliance: www.aeq.com/shop

CUSTOMER CARE AND SERVICE

Always use original spare parts.

When contacting our Authorised Service Centre, ensure that you have the following data available: Model, PNC, Serial Number.

The information can be found on the rating plate.

⚠ Warning / Caution-Safety information

(i) General information and tips

Environmental information

Subject to change without notice.

1. A SAFETY INFORMATION

Before beginning the installation and use of this appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damages that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.



- Read the supplied instructions.

1.1 Children and vulnerable people safety



WARNING!

Risk of suffocation, injury or permanent disability.

- This appliance can be used by children aged from 8
 years and above and persons with reduced physical,
 sensory or mental capabilities or lack of experience
 and knowledge if they have been given supervision or
 instruction concerning the use of the appliance in a
 safe way and understand the hazards involved.
- Children between 3 and 8 years of age and persons with very extensive and complex disabilities shall be kept away unless continuously supervised.
- Children of less than 3 years of age should be kept away unless continuously supervised.
- Do not let children play with the appliance.
- Keep all packaging away from children and dispose of it appropriately.
- Keep detergents away from children.
- Keep children and pets away from the appliance when the door is open.
- If the appliance has a child safety device, it should be activated.
- Children shall not carry out cleaning and user maintenance of the appliance without supervision.

1.2 General Safety

- Do not change the specification of this appliance.
- If the tumble dryer is put on top of a washing machine, use the stacking kit. The stacking kit, available from your authorized vendor, can be used only with the appliance specified in the instructions supplied with the accessory. Read it carefully before installation (refer to the Installation leaflet).
- The appliance can be installed as freestanding or below a kitchen counter with correct space (refer to the Installation leaflet).
- Do not install the appliance behind a lockable door, a sliding door or a door with a hinge on the opposite side, that would prevent the appliance door from being fully open.
- The ventilation opening in the base must not be covered by a carpet, mat, or any floor covering.
- WARNING: The appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.
- Connect the mains plug to the mains socket only at the end of the installation process. Make sure that the mains plug is accessible after installation.
- If the mains power supply cable is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons to avoid an electrical hazard.
- Do not exceed the maximum load of 8 kg (refer to the "Programme chart" chapter).
- Do not use the appliance if items have been soiled with industrial chemicals.
- Wipe away lint or packaging debris that has accumulated around the appliance.
- Do not run the appliance without a filter. Clean the lint filter before or after each use.
- Do not dry unwashed items in the tumble dryer.

- Items that have been soiled with substances such as cooking oil, acetone, alcohol, petrol, kerosene, spot removers, turpentine, waxes and wax removers should be washed in hot water with an extra amount of detergent before being dried in the tumble dryer.
- Items such as foam rubber (latex foam), shower caps, waterproof textiles, rubber backed articles and clothes or pillows fitted with foam rubber pads should not be dried in the tumble dryer.
- Fabric softeners, or similar products, should only be used as specified by the product manufacturer's instructions.
- Remove all objects from items that could be a source of fire ignition such as lighters or matches.
- WARNING: Never stop a tumble dryer before the end of the drying cycle unless all items are quickly removed and spread out so that the heat is dissipated.
- Before any maintenance operation, deactivate the appliance and disconnect the mains plug from the socket.

2. SAFETY INSTRUCTIONS

2.1 Installation

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Follow the installation instructions supplied with the appliance.
- Always take care when moving the appliance as it is heavy. Always use safety gloves and enclosed footwear.
- Do not install or use the appliance where the temperature can be lower than 5°C or higher than 35°C.
- The floor area on which the appliance is to be installed must be flat, stable, heat resistant and clean.
- Make sure that there is air circulation between the appliance and the floor.
- Always keep the appliance vertical when it is being moved.
- The rear surface of the appliance must be put against a wall.

 When the appliance is in its permanent position, check if it is levelled correctly with the aid of a spirit level. If it is not, adjust the feet accordingly.

2.2 Electrical connection



↑ WARNING!

Risk of fire and electric shock.

- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- The appliance must be earthed.
- Make sure that the parameters on the rating plate are compatible with the electrical ratings of the mains power supply.

- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Do not touch the mains cable or the mains plug with wet hands.
- This appliance complies with the E.E.C. Directives.

2.3 Use



WARNING!

Risk of injury, electric shock, fire, burns or damage to the appliance.

- This appliance is for household use only.
- Do not dry damaged (torn, frayed) items that contain padding or fillings.
- Only dry fabrics which are suitable for drying in a tumble dryer. Follow the instructions on the fabric label.
- If you have washed your laundry with a stain remover start an extra rinse cycle before you start the dryer.
- Do not drink or prepare food with the condensed water/distilled water. It can cause health problems to people and pets.
- Do not sit or stand on the open door of the appliance.
- Do not dry dripping wet clothes in a tumble dryer.

2.4 Care and cleaning



WARNING!

Risk of injury or damage to the appliance.

- Do not use water spray and steam to clean the appliance.
- Clean the appliance with a moist soft cloth. Only use neutral detergents. Do not use any abrasive products, abrasive cleaning pads, solvents or metal objects.
- To prevent damage to the cooling system be careful when you clean the appliance.

2.5 Compressor



WARNING!

Risk of damage to the appliance.

 The compressor and its system in the tumble dryer is filled with the special agent which is free from fluoro-chlorohydrocarbons. This system must stay tight. The damage of the system can cause a leakage.

2.6 Disposal




WARNING!

Risk of injury or suffocation.

- Disconnect the appliance from the mains electrical and water supplies.
- Cut off the mains electrical cable close to the appliance and dispose of it.
- Remove the door catch to prevent children or pets from becoming trapped in the drum.
- Dispose of the appliance in accordance with local requirements for the disposal of Waste Electrical and Electronic Equipment (WEEE).

3. PRODUCT DESCRIPTION




- 1 Water container
- 2 Control panel
- 3 Appliance door
- 4 Filter
- 5 Rating plate

- 6 Airflow slots
- 7 Condenser lid
- 8 Condenser cover
- 9 Adjustable feet

(i)

For ease of loading laundry or ease of installation the door is reversible. (see separate leaflet).

4. CONTROL PANEL



- 1 Program dial
- 2 Display
- 3 Start/Pause button
- 4 Options

- 5 On/Off button
- 6 Programs

4.1 Display



Symbol on the display	Symbol description		
30'-20h	delay start selection (30min-20h)		
1:50	cycle time indication		
€,	indicator: drain the water container		
	indicator: <i>clean the filter</i>		
⇒	indicator: check the condenser		
ī	child lock on		

Symbol on the display	Symbol description
10:2:00	time programme selection (10min-2h)

5. PROGRAM

Program	Load ¹⁾	Properties / Fabric mark	
Eco	8 kg	Cycle to be used to dry cotton with "cotton cupboard" dryness level, with maximum energy saving.	/ ©O
Extra Dry	8 kg	Drying level: extra dry.	/ ©0
Cupboard Dry	8 kg	Drying level: cupboard dry.	/00
Iron Dry	8 kg	Drying level: suitable for ironing.	/ ©0
	△ Syr	nthetics and mixed	
Extra Dry	3,5 kg	Drying level: extra dry.	/ ©©©
Cupboard Dry	3,5 kg	Drying level: cupboard dry.	/000
Iron Dry	3,5 kg	Drying level: suitable for ironing.	/000
MIX Mixed	3 kg	Cotton and synthetic fabrics.	/000
W ool	1 kg	Woollen fabrics. Gentle drying of washable woollens. Remove items immediately when the programme is completed.	
W Silk	1 kg	Silk suitable for tumble drying.	/000
Easy Iron	1 kg (or 5 shirts)	Easy care fabrics for which a minimum of ironing is necessary. The drying results can be different from one type of fabric to another. Shake the items before putting them in the appliance. When the programme has ended, immediately remove the items and put them on a hanger.	

Program	Load ¹⁾	Properties / Fabric mark	
Bed Linen	3 kg	Bed linen such as single and double sheets, pillowcases, duvet cover.	/000
T Sports	2 kg	Sportswear, thin and light fabrics, microfiber, polyester.	/ ©©
Time Dry	5 kg	With this programme you can use the Time Dry option and set the programme duration. Drying time should be adequate to the load, e.g. 2h for 5 kg of cotton.	

¹⁾ The maximum weight refers to dry items.

5.1 Programmes and options selection

	Options				
Programmes ¹⁾	☑ Anticrease	Time Dry			
	Octtons				
Eco	•				
* Extra Dry	•				
① Cupboard Dry	•				
☐ Iron Dry	•				
	⚠ Synthetics and mixed				
* Extra Dry	•				
① Cupboard Dry	•				
☐ Iron Dry	•				
Mixed	•				
W ool		■ 2)			
₩ Silk	•				

²⁾ The Cottons Eco programme is the "Standard cotton programme" according to Commission Regulation EU No. 392/2012. It is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for drying wet cotton laundry.

	Options		
Programmes 1)	☑ Anticrease	Time Dry	
Easy Iron	•		
Bed Linen	•		
TS Sports	•		
Time Dry	•	•	

¹⁾ Together with the programme you can set 1 or more options.

5.2 Consumption data

Program	Spun at / residual humidity	Drying time ¹⁾	Energy consump- tion ²⁾
	Cottons ECO 8 kg		
Cupboard Dry	1400 rpm / 50%	147 min	2,03 kWh
	1000 rpm / 60%	179 min	2,60 kWh
Iron Dry	1400 rpm / 50%	113 min	1,47 kWh
	1000 rpm / 60%	135 min	1,79 kWh
Cottons ECO 4 kg			
Cupboard Dry	1400 rpm / 50%	86 min	1,14 kWh
	1000 rpm / 60%	102 min	1,38 kWh
Synthetics 3,5 kg			
Cupboard Dry	1200 rpm / 40%	58 min	0,71 kWh
	800 rpm / 50%	72 min	0,90 kWh

¹⁾ For partial loads, the cycle time is shorter and appliance uses less energy.

6. OPTIONS

6.1 ¹ Anticrease

Extends up to 120 minutes the anticrease phase (30 minutes) at the end of the drying cycle. After drying phase drum rotates from time to time to prevent creases. Laundry can be removed during the anti-crease phase.

²⁾ See chapter OPTIONS: Time Dry on Wool programme

²⁾ Improper ambient temperature and/or poorly centrifuged laundry can prolong cycle time and increase the energy consumption.

6.2 प≤ Buzzer

The sound is heard at the:

- cycle end
- start and end of crease guard phase The buzzer option is by default always on. You can use this option to activate or deactivate the sound.

6.3 ^U Time Dry

For cottons, synthetics and mixed. Lets the user to set drying time from minimum 10 min to maximum of 2 hours (in 10 min steps). When this option is maximum, load indicator disappears.

6.4 [⊕] Time Dry on Wool program

Option applicable to Wool program to adjust final dryness level to more dry or less dry.

6.5 🕒 Delay Start



Lets to delay the start of a drying program from minimum of 30 minutes to maximum of 20 hours.

- 1. Set the drying program and options.
- 2. Touch Delay Start button again and again.

Time of delay is on the display (e.g. 1 2 hours.)

3. To activate ⊕ Delay Start option, touch the S Start/Pause button.
Time to start decreases on the display.

7. BEFORE FIRST USE



Rear drum packaging is removed automatically when dryer is activated for the first time. Possible to hear some noise

Before you use the appliance for the first time:

- Clean the tumble dryer drum with a moist cloth.
- Start a 1 hour programme with moist laundry.

(i)

At the beginning of the drying cycle (first 3-5 min) there could be a slightly higher sound level. This is due to the compressor starting up. This is normal for compressor powered appliances such as refrigerators and freezers.

8. DAILY USE

8.1 Preparing the laundry

- Close the zips.
- Close the fasteners of duvet covers.
- Do not dry ties or ribbons loose (e.g. apron ribbons). Tie them before you start a programme.
- Remove all items from pockets.
- Turn items with the internal layer made of cotton inside out. Cotton layer must be faced outwards.
- Always set the programme suitable for the type of laundry.

- Do not put light and dark colours together.
- Use suitable programme for cottons, jersey and knitwear to reduce shrinkage.
- Do not exceed the maximum load stated in the programmes chapter or shown on the display.
- Dry only the laundry that is suitable for tumble drying. Refer to the fabric label on the items.

 Do not dry large and small items together. Small items can be trapped inside the large items and remain wet.

Fabric label	Description
	Laundry is suitable for tumble drying.
©	Laundry is suitable for tumble drying at higher temperatures.
0	Laundry is suitable for tumble drying at low temperatures only.
	Laundry is not suitable for tumble drying.

8.2 Loading the laundry




CAUTION!

Ensure the laundry is not trapped between the appliance door and the rubber seal.

- 1. Pull open the appliance door.
- 2. Load the laundry one item at a time.
- **3.** Close the appliance door.


8.3 Turning on the appliance



To turn on the appliance:

Push the On/Off button.
If the appliance is on, some indicators appear on the display.

8.4 Setting a programme



Use the programme dial to set the programme.


The possible time to complete the programme appears on the display.



The drying time you see on the display, when the cotton programme is selected, is related to the load of 5 kg and standard conditions. Real drying time will depend on type of the load (quantity and composition), the room temperature and the humidity of your laundry after spin drying phase.

8.5 Options

Together with the programme you can set 1 or more special options.



To activate or deactivate an option touch the relevant button or a two button combination.

its symbol appears on the display or the led above the corresponding button lights up.


8.6 Child lock option

The child lock can be set to prevent children from playing with the appliance. The child lock option locks all touch buttons and the program dial (this option does not lock the ① On/Off button).

You can activate the child lock option:

- before you touch the Start/Pause button the appliance cannot start
- after you touch the Start/Pause button programs and option selection is unavailable.

Child lock option activation:




- 1. Turn the dryer on.
- 2. Select 1 of the available programs.
- **3.** Touch and hold down 2 buttons at the same time.

The symbol appears on the display.

 To deactivate the child lock, touch the above buttons again until the symbol disappears.

8.7 Starting a program



To start the program:

Touch the **Start/Pause** button. The appliance starts and the LED above the button stops flashing and stays on.

8.8 Program change

To change a program:

- 1. Push the On/Off button to turn the appliance off.
- 2. Push the ① On/Off button again to turn on the appliance.
- 3. Set a new program.

8.9 Program end



Clean the filter and drain the water container after each drying cycle. (See chapter CARE AND CLEANING.)

If the drying cycle is finished, the symbol ☐ appears on the display. If the ☐ ■ Buzzer option is activated, the acoustic signal sounds intermittently for 1 minute.



If you do not turn off the appliance, the anti-crease phase starts (not active with all programs). Flashing symbol signals the execution of the anticrease phase. Laundry can be removed during this phase.

To remove the laundry:

- 1. Push the ① On/Off button for 2 seconds to turn the appliance off.
- 2. Open the appliance door.

3. Remove the laundry.

9. HINTS AND TIPS

9.1 Ecological hints

- Spin the laundry well before drying.
- Do not exceed the load sizes which are specified in the programs chapter.
- Clean the filter after each drying cycle.
- Do not use fabric softener to wash and then dry. In the tumble dryer laundry becomes soft automatically.
- Use distilled water like that used for steam ironing. If it is necessary, clean the distilled water before (e.g. with a coffee filter) to remove any particles.
- Always keep the airflow slots at the bottom of the appliance clear.
- Make sure there is good airflow where the appliance is to be installed.

9.2 Adjustment of default dryness level

To change the default dryness level:

- 1. Turn the appliance on.
- 2. Select 1 of the available programs.
- 3. Touch and hold down the The Anticrease and Time Dry buttons at the same time.

One of the symbols appears on the display:

- ☐☐ Maximum dryness
- **CO**= Extra dryness
- **□** Standard dryness
- 4. Touch the Slart/Pause button repeatedly until you reach the desired dryness level.

Dryness lev- el		Display symbol
Maximum dryness	‡[555]	C 0 _

4. Close the appliance door.

Dryness lev- el		Display symbol
Extra dry- ness	+ [555]	CO=
Standard dryness	[SSS]	C 03

5. To memorise the setting touch and hold down the Anticrease and Time Dry buttons at the same time for approximately 2 seconds.

9.3 Deactivating the tank indicator ♠

The water container indicator is activated by default. It illuminates at the end of the drying cycle or during the cycle if the water reservoir is full. If the draining kit is installed the water container is drained automatically and the indicator can be deactivated.

To deactivate the indicator:

- 1. Turn the appliance on.
- 2. Select 1 of the available programs.
- 3. Touch and hold down ☐ Buzzer and ☐ Time Dry buttons at the same time.

One of 2 configurations is possible:

- the Tank indicator: is on if the symbol _ _ l appears the water container indicator is permanently activated
- the Tank indicator: is off if the symbol _ _ _ appears - the water container indicator is permanently deactivated

10. CARE AND CLEANING


10.1 Cleaning the filter

At the end of each cycle the Filter symbol comes on the display and you must clean the filter.




The filter collects the fluff during the drying cycle.

1. Open the door. Pull the filter up.



2. Push the hook to open the filter.




3. Use a moist hand to clean both parts of the filter.



4. If necessary, clean the filter with a vacuum cleaner. Close the filter.

 If necessary, remove fluff from the filter socket and gasket. You can use a vacuum cleaner. Place the filter back inside the filter socket.




10.2 Emptying the water container

Empty the condensed water container after each drying cycle.


If the condensed water container is full, the programme stops automatically. The Ank symbol comes on the display and you must empty the water container.

To empty the water container:

1. Pull the water container out keeping it in a horizontal position.



2. Pull the plastic connection out and drain the water into a basin or equivalent receptacle.



- **3.** Push the plastic connection back in and place the water container back into position.
- **4.** To continue the programme press the Start/Pause button.

10.3 Cleaning the condenser

If the symbol \Rightarrow Condenser flashes on the display, inspect the condenser and its compartment. If it is dirty, clean it. Do the check not less than once a 6 months.




WARNING!


Do not touch the metal surface with bare hands. Risk of injury. Wear protective gloves. Clean carefully to avoid damaging the metal surface.

To inspect:


1. Open the door. Pull the filter up.



2. Open the condenser cover.




Turn the lever to unlock the condenser lid.



4. Lower the condenser lid.



5. If necessary, remove the fluff from the condenser and its compartment. You can use a wet cloth and/or a vacuum cleaner with a brush attachment.



- 6. Close the condenser lid.
- **7.** Turn the lever until it clicks into position.
- 8. Put the filter back.

10.4 Cleaning the drum



WARNING!

Disconnect the appliance before you clean it.

Use a standard neutral soap detergent to clean the inner surface of the drum and drum lifters. Dry the cleaned surfaces with a soft cloth.



CAUTION!

Do not use abrasive materials or steel wool to clean the drum.

10.5 Cleaning the control panel and housing

Use a standard neutral soap detergent to clean the control panel and housing.

Use a moist cloth to clean. Dry the cleaned surfaces with a soft cloth.



CAUTION!

Do not use furniture cleaning agents or cleaning agents which can cause corrosion.

10.6 Cleaning the airflow slots

Use a vacuum cleaner to remove fluff from the airflow slots.

11. TROUBLESHOOTING

Problem ¹⁾	Possible cause	Remedy
	The tumble dryer is not connected to the mains supply.	Connect it to the mains socket. Check the fuse in the fuse box (domestic installation).
	The door is open.	Close the door.
The tumble dry- er does not op- erate.	The O On/Off button was not pushed.	Push the ① On/Off button.
	The Start/Pause button was not touched.	Touch the Start/Pause button.
	The appliance is in standby mode.	Push the \bigcirc On/Off button.
	Incorrect programme selection.	Select a suitable programme. ²⁾
	The filter is clogged.	Clean the filter. 3)
	Iron Dry.4)	Change SSSS Dryness option to a higher level.
Unsatisfactory	The load was too large.	Do not exceed the maximum load size.
drying result.	The airflow slots are clogged.	Clean the airflow slots at the bottom of the appliance.
	There is some dirt on the humidity sensor in the drum.	Clean the front surface of the drum.
	The dryness level was not set to the desired level.	Adjust the dryness level. 5)
	The condenser is clogged.	Clean the condenser. ³⁾

Problem ¹⁾	Possible cause	Remedy	
The loading	The filter is not locked into position.	Put the filter in the correct position.	
close	Laundry is trapped between the door and the seal.	Remove trapped items and close the door.	
It is not possible to change the programme or option.	After a cycle starts it is not possible to change the programme or option.	Turn the tumble dryer off and on. Change the programme or option as required.	
It is not possible to select an op- tion. An acoustic signal is emit- ted.	The option you tried to select is not available for the selected programme.	Turn the tumble dryer off and on. Change the programme or option as required.	
Unexpected duration time appears on the display.	The drying duration is calculated according to load size and dampness.	This is automated - the appliance is working correctly.	
A programme is inactive.	The water container is full.	Drain the water container, push the I Start/Pause button. 3)	
The drying cycle is too short.	The load size is small.	Select a time programme. The time value must be related to the load. To dry one item or a small amount of laundry we recommend short drying times.	
	The laundry is too dry.	Select an appropriate time programme or a higher dryness level (e.g. ** Extra Dry)	

Problem ¹⁾	Possible cause	Remedy
Drying cycle too long ⁶⁾	The filter is clogged.	Clean the filter.
	The load is too large.	Do not exceed the maximum load size.
	The laundry was not spun sufficiently.	Spin the laundry well in the washing machine.
	Too low or too high room temperature - this is not the appliance malfunction.	Ensure a room temperature higher than +5°C and lower than +35°C. Optimal room temperature to achieve best drying results is between 19°-24°C.

¹⁾ If there is an error message on the display (e.g. **E51**): Turn the tumble dryer off and on. Select a new programme. Touch the Start/Pause button. If the appliance does not operate contact the service centre and provide the error code.

12. TECHNICAL DATA

Height x Width x Depth	850 x 600 x 600 mm (maximal 665 mm)	
Max. depth with the appliance door open	1100 mm	
Max. width with the appliance door open	950 mm	
Adjustable height	850 mm (+ 15 mm - feet regulation)	
Drum volume	118	
Maximum load volume	8 kg	
Voltage	230 V	
Frequency	50 Hz	
Sound power level	66 dB	
Total power	900 W	
Energy efficiency class	A+	
Energy consumption on the standard cotton programme with the full load. 1)	2,60 kWh	
Energy consumption on the standard cotton programme with the partial load. ²⁾	1,38 kWh	

²⁾ Follow the programme description — see the PROGRAMMES chapter .

³⁾ See the CARE AND CLEANING chapter.

⁴⁾ Only dryers with the Dryness option.

⁵⁾ See the HINTS AND TIPS chapter .

⁶⁾ Note: After a maximum of 5 hours the drying cycle ends automatically.

Annual energy consumption ³⁾	308,20 kWh	
Left-on mode power absorption ⁴⁾	0,50 W	
Off mode power absorption ⁴⁾	0,50 W	
Type of use	Household	
Allowed ambient temperature	+ 5°C to + 35°C	
Level of protection against ingress of solid particles and moisture ensured by the pro- tective cover, except where the low voltage equipment has no protection against mois- ture	IPX4	
This product contains fluorinated greenhouse gases, hermetically sealed		
Gas designation	R134a	
Weight	0,300 kg	
Global-warming potential (GWP)	1430	

¹⁾ With reference to EN 61121. 8 kg of cotton centrifuged at 1000 rpm.

The information given in the chart above is compliant with the EU Commission regulation 392/2012 implementing directive 2009/125/EC.

13. ACCESSORIES

13.1 Stacking kit



Accessory name: SKP11, STA9

Available from your authorised vendor.

Stacking kit can be used only between washing machines and tumble dryers specified in the leaflet. See the leaflet attached.


Read carefully the instructions supplied with the accessory.

²⁾ With reference to EN 61121. 4 kg of cotton centrifuged at 1000 rpm.

³⁾ Energy consumption per year in kWh, based on 160 drying cycles of the standard cotton programme at full and partial load, and the consumption of the low-power modes. Actual energy consumption per cycle will depend on how the appliance is used (REGULATION (EU) No. 392/2012).

⁴⁾ With reference to EN 61121.

13.2 Draining kit



Accessory name: DK11.

Available from your authorised vendor (can be attached to some types of tumble dryer)

For thorough draining of the condensed water into a basin, siphon, gully, etc. After installation, the water container is drained automatically. The water container must stay in the appliance.

The installed hose must be minimum 50 cm to maximum 100 cm from floor level. The hose cannot be in a loop. Decrease the length of the hose if necessary.

Read carefully the instructions supplied with the accessory.

13.3 Pedestal with drawer



Accessory name: PDSTP10, E6WHPED2.

Available from your authorised vendor.

For increasing the height of the appliance in order to ease loading and unloading of laundry.

The drawer can be used for laundry storage e.g.: towels, cleaning products etc.

Read carefully the instructions supplied with the accessory.

14. PRODUCT INFORMATION SHEET IN REFERENCE TO E.U. REGULATION 1369/2017

Product Information Sheet	
Trade Mark	AEG
Model	T7DBP731K, PNC916098454
Rated capacity in kg	8
Air vented or condenser tumble dryer	Condenser
Energy efficiency class	A+
Energy consumption in kWh per year, based on 160 drying cycles of the standard cotton programme at full and partial load, and the consumption of the low-power modes. Actual energy consumption per cycle will depend on how the appliance is used.	308,20

Energy consumption of the standard cotton programme at full load in kWh Energy consumption of the standard cotton programme at partial load in kWh Power consumption of the off-mode in W 0,50 Power consumption in left-on mode in W 0,50 Duration of the left on mode in minutes 10 The 'standard cotton programme' used at full and partial load is the standard drying programme to which the information in the label and the fiche relates, this programme is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for cotton. Weighted programme time of the 'standard cotton programme at full and partial load' in minutes Programme time of the 'standard cotton programme at full load' in minutes Programme time of the 'standard cotton programme at partial load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB Built in appliance Y/N No	Automatic tumble drier or non-automatic tumble drier	Automatic
partial load in kWh Power consumption of the off-mode in W 0,50 Power consumption in left-on mode in W 0,50 Duration of the left on mode in minutes 10 The 'standard cotton programme' used at full and partial load is the standard drying programme to which the information in the label and the fiche relates, this programme is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for cotton. Weighted programme time of the 'standard cotton programme at full and partial load' in minutes Programme time of the 'standard cotton programme at full load' in minutes Programme time of the 'standard cotton programme at partial load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66		2,60
Power consumption in left-on mode in W 0,50 Duration of the left on mode in minutes 10 The 'standard cotton programme' used at full and partial load is the standard drying programme to which the information in the label and the fiche relates, this programme is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for cotton. Weighted programme time of the 'standard cotton programme at full and partial load' in minutes Programme time of the 'standard cotton programme at full 179 load' in minutes Programme time of the 'standard cotton programme at partial load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66		1,38
Duration of the left on mode in minutes 10 The 'standard cotton programme' used at full and partial load is the standard drying programme to which the information in the label and the fiche relates, this programme is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for cotton. Weighted programme time of the 'standard cotton programme at full and partial load' in minutes Programme time of the 'standard cotton programme at full 179 load' in minutes Programme time of the 'standard cotton programme at partial load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66	Power consumption of the off-mode in W	0,50
The 'standard cotton programme' used at full and partial load is the standard drying programme to which the information in the label and the fiche relates, this programme is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for cotton. Weighted programme time of the 'standard cotton programme at full and partial load' in minutes Programme time of the 'standard cotton programme at full 179 load' in minutes Programme time of the 'standard cotton programme at partial 102 load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66	Power consumption in left-on mode in W	0,50
is the standard drying programme to which the information in the label and the fiche relates, this programme is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for cotton. Weighted programme time of the 'standard cotton programme at full and partial load' in minutes Programme time of the 'standard cotton programme at full load' in minutes Programme time of the 'standard cotton programme at partial load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66	Duration of the left on mode in minutes	10
gramme at full and partial load' in minutes Programme time of the 'standard cotton programme at full 179 load' in minutes Programme time of the 'standard cotton programme at partial 102 load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton 81 programme at full and partial load' Sound power level in dB 66	is the standard drying programme to which the information in the label and the fiche relates, this programme is suitable for drying normal wet cotton laundry and it is the most efficient	
Programme time of the 'standard cotton programme at partial lo2 load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66	5 1 5	135
load' in minutes Condensation efficiency class on a scale from G (least efficient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66	1 0	179
cient) to A (most efficient) Average condensation efficiency of the standard cotton programme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66		102
gramme at full load as a percentage Average condensation efficiency of the standard cotton programme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66		В
gramme at partial load as a percentage Weighted condensation efficiency for the 'standard cotton programme at full and partial load' Sound power level in dB 66	, ,	81
programme at full and partial load' Sound power level in dB 66		81
<u>'</u>	· · ·	81
Built in appliance Y/N No	Sound power level in dB	66
	Built in appliance Y/N	No

The information given in the chart above is compliant with the EU Commission regulation 392/2012 implementing directive 2009/125/EC.

15. ENVIRONMENTAL CONCERNS

Recycle materials with the symbol $\stackrel{\longleftarrow}{\smile}$. Put the packaging in relevant containers to recycle it. Help protect the environment and human health by recycling waste of electrical and electronic appliances. Do not dispose of

appliances marked with the symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.

www.aeg.com/shop













CE